



DTA Race Electronics  
Unit 10, Boston Court  
Kansas Ave  
Manchester  
M50 2GN  
England

Tel: (+44) (0)161 877 1419  
Fax: (+44) (0)161 877 7086  
Email: office@dtafast.co.uk  
Website: www.dtafast.co.uk

---

## Xdash Loom V2.0 From 28/11/2013

### Pin Outs Of Connectors

#### Power

- 1 = 12 Volts
- 2 = Night Dimming Input (Connect to light switch)
- 3 = CAN H
- 4 = CAN L
- 5 = Gnd

#### GPS

- 1 = 5V
- 2 = Tx
- 3 = Rx
- 4 = Agnd

#### Tank Level

- 1 = 5V
- 2 = Signal (Ana 2) (note only Signal needs connecting normally)
- 3 = AGnd

#### Lap

- 1 = 12 V
- 2 = Signal
- 3 = Gnd

#### Poil/Gear

- 1 = 5V
- 2 = Ana 4 (Do not Connect Oil Pressure  
and Gear to the Dash, Connect to Engine ECU)
- 3 = Ana 0
- 4 = AGnd

#### Brake

- 1 = 5V
- 2 = Ana 1 / Front Brake
- 3 = Ana 3 / Rear Brake
- 4 = AGnd